




Stove




A x 1




B x 1




C x 2



D x 1



E x 1




F x 2




G x 17

Warning! Adult assembly required. For the safe use of the toy - please make sure to follow all the steps in the instruction carefully to avoid choking hazard with small parts/loose screws after assembly.


1




2



3



4



5

